

ALPHABETICAL INDEX

GI



MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

ALPHABETICAL INDEX

A

AAC/V - Wiring diagramEC-38, 69, 367
ABS - Wiring diagramBR-3, 10
A/C relayHA-25, 35
A/C trouble diagnoses (auto A/C)HA-26
A/C trouble diagnoses (manual A/C)HA-4, 26
A/C, A - Wiring diagramHA-27
A/C, M - Wiring diagramHA-6, 9, 12
ACC/SW - Wiring diagramEC-831
Accelerator control systemFE-2
Accelerator position sensor.....EC-607, 861
Accelerator switch (F/C).....EC-829
Air bagRS-3
Air bag disposal.....RS-11
Air cleaner filter replacement (KA24DE engine)MA-12
Air cleaner filter replacement (YD engine)MA-21
Air cleaner filter replacement (ZD engine)MA-29
Air conditioner cut control.....EC-97, 505, 756
Air flow meter - See Mass air flow sensor.....EC-212, 220
AIRREG - Wiring diagram.....EC-76
Alternator.....EL-24
Angular tightening application.....EM-3
Antenna.....EL-127
Anti-lock brake system - Wiring diagramBR-2, 3, 9
A/T - Wiring diagram - AT - MAIN.....AT-4
A/T - Wiring diagram - AT - VSS A/T.....AT-6
A/T IND - Wiring diagramEL-105
AT indicator lampEL-105
A/T shift lock system.....AT-34
A/T shift lock system - Wiring diagram.....AT-34
A/T Wiring diagram - AT - ENG SSAT-24
A/T Wiring diagram AT - BA/FTS.....AT-22
A/T Wiring diagram AT - LPSVAT-26
A/T Wiring diagram AT - NONDTCAT-28
A/T Wiring diagram AT - OVRCSVAT-18
A/T Wiring diagram AT - SSV/A.....AT-14
A/T Wiring diagram AT - SSV/B.....AT-16
A/T Wiring diagram AT - TCVAT-20
A/T Wiring diagram AT - TPS.....AT-11
A/T Wiring diagram AT - VSSMTRAT-9
AudioEL-121
AUDIO - Wiring diagram.....EL-121
Automatic choke.....EC-55
Auxiliary air control (AAC) valve.....EC-38, 364

B

Back-up lampEL-47
BACK/L - Wiring diagram.....EL-47
Basic inspectionEC-155, 536, 784
Battery.....EL-13
BOOST - Wiring diagram.....EC-694, 944

Boring/horning cylinder block (ZD engine)EM-154
BRK/SW - Wiring diagramEC-677, 930
Bumper, frontBT-2

C

Camshaft (ZD engine).....EM-111
Camshaft inspection (YD engine).....EM-54
Camshaft inspection (ZD engine)EM-112
Camshaft position sensor (CMPS)EC-19, 339
Canister-See EVAP canisterEC-98
Center case (Transfer).....TF-3
CHARGE - Wiring diagram.....EL-20
Charge air pressure sensorEC-692, 942
Charging systemEL-20
CHIME - Wiring diagram.....EL-106
CIGAR - Wiring diagramEL-118
Cigarette lighter.....EL-118
CKPS - Wiring diagram.....EC-335, 420
ClockEL-119
CLOCK - Wiring diagramEL-119
Closed throttle position switchEC-370
CMPS - Wiring diagram.....EC-19, 20, 63, 342
Collision diagnosis.....RS-37
Combination lamp, front, removal and installationBT-2
Combination meter.....EL-61
Combination switch.....EL-25
Compression pressure (YD engine)EM-17
Compression pressure (ZD engine)EM-92
Connecting rod (YD engine).....EM-76
Connecting rod (ZD engine)EM-153
Connecting rod bearing clearance (YD engine)EM-81
Connecting rod bearing clearance (ZD engine)EM-157
Connecting rod bushing clearance (YD engine)EM-84
Connecting rod bushing clearance (ZD engine)EM-153
CONSULT for engine.....EC-139, 526, 773
Control lever (Transfer).....TF-2
COOL/F - Wiring diagram (KA24DE engine)LC-2
COOL/F - Wiring diagram (QD & TD engines)LC-3
Coolant replacement (YD engine)MA-16
Coolant replacement (ZD engine)MA-25
Cooling circuit (YD engine).....LC-11
Cooling circuit (ZD engine).....LC-24
Cooling fan (YD engine).....LC-16
Cooling fan (ZD engine).....LC-30
Cooling fan control.....EC-413, 581, 834
Cooling fan control system (KA24DE engine)LC-2
Cooling fan control system (QD & TD engines)LC-3
Cooling fan control system (YD engine)LC-17

ALPHABETICAL INDEX

Cooling fan control system (ZD engine).....LC-31
 Counter gear (Transfer).....TF-4
 Crank angle sensor built into distributor
 - See Camshaft position sensor.....EC-19, 339
 Crankcase emission control system -
 See positive crankcase
 ventilationEC-101, 506, 757
 Crankcase ventilation system - See
 Positive crankcase ventilation..EC-101, 506, 757
 Crankshaft (YD engine)EM-79
 Crankshaft (ZD engine)EM-156
 Crankshaft position sensor (OBD).....EC-333, 418
 Crankshaft position sensor (OBD) cog
 chippingEC-418
 Crankshaft position sensor (POS)EC-19
 Crankshaft position sensor (REF).....EC-19
 Crankshaft position sensor (TDC)EC-626, 879
 Cylinder block (YD engine).....EM-70
 Cylinder block (ZD engine).....EM-146
 Cylinder head (YD engine)EM-50
 Cylinder head (ZD engine)EM-133
 Cylinder head bolt tightening (ZD
 engine)EM-135
 Cylinder head gasket selection (ZD
 engine)EM-135

D

Data link connectorEC-102
 Data link connector for Consult ...EC-102, 526, 773
 Daytime light system.....EL-32
 DEF - Wiring diagram.....EL-120
 Detonation sensor - See Knock sensor.....EC-329
 Diagnosis sensor unit.....RS-5
 Diagnostic trouble code (DTC) for OBD
 systemEC-78, 520, 768
 Diagnostic trouble code (DTC) inspec-
 tion priority chart.....EC-169
 Dim-dip lamp systemEL-36
 DIMDIP - Wiring diagram.....EL-36
 DimensionsGI-12
 DistributorEC-95
 Distributor ignition (DI) system.....EC-95
 D/LOCK - Wiring diagram.....EL-146
 Drive belt inspection (YD engine).....MA-13
 Drive belt inspection (ZD engine).....MA-22
 Drive chain (Transfer)TF-4
 DTC work supportEC-147
 DTRL - Wiring diagram.....EL-32

E

ECCS-D control moduleEC-555, 593, 673, 675,
 677, 685, 690, 803, 846,
 926, 928, 930, 935, 940
 ECM input/output signal.....EC-179, 555, 803
 ECM relay.....EC-13
 ECMRLY - Wiring diagram.....EC-686, 936

ECTS - Wiring diagram.....EC-28, 65, 236
 EGR - Wiring diagram.....EC-699, 950
 EGR volume control valveEC-697, 947
 EGRC/V - Wiring diagram.....EC-486
 Electrical ignition system.....EC-95
 Electronic fuel injection
 pump.....EC-511, 600, 634, 641, 648, 655, 662,
 665, 706, 761, 854, 887, 894, 901,
 908, 915, 918, 957
 Engine control circuit
 diagramEC-60, 89, 500, 751
 Engine control component parts
 locationEC-87, 747
 Engine control module (ECM).....EC-377
 Engine control system diagram and
 chartEC-90, 501, 752
 Engine coolant temperature sensor
 (ECTS)EC-234, 572, 820
 Engine fail-safe system.....EC-170
 Engine oil filter replacement (YD
 engine)MA-15
 Engine oil filter replacement (ZD
 engine)MA-24
 Engine oil replacement (YD engine).....MA-14
 Engine oil replacement (ZD engine).....MA-23
 Engine outer component parts
 (KA24DE engine)EM-12
 Engine removal (YD engine)EM-67
 Engine removal (ZD engine).....EM-143
 Engine serial numberGI-10
 EVAP canister.....EC-98
 EVAP canister purge volume control
 solenoid valve.....EC-352
 Evaporative emission (EVAP) system.....EC-98
 Exhaust manifold (KA24DE engine).....EM-12
 Exhaust manifold (ZD engine)EM-100
 Exhaust systemFE-6
 Exterior.....BT-6

F

Fast idle cam (FIC)EC-104
 FCUT - Wiring diagram.....EC-56, 490
 FICD - Wiring diagram.....EC-48, 49, 459, 491
 FIPO - Wiring diagramEC-57
 Fluids.....MA-10
 Flywheel runout (YD engine)EM-84
 Flywheel runout (ZD engine)EM-185
 Fog lamp, rearEL-50
 FPCM - Wiring diagramEC-58
 F/PUMP - Wiring diagram.....EC-46, 74, 449
 Freeze frame dataEC-119
 Front bumperBT-2
 Front case (Transfer)TF-3
 Front combination lamp removal and
 installationBT-2
 Front drive shaft (Transfer).....TF-4
 Front passenger air bag.....RS-3, 9
 Front washerEL-109

ALPHABETICAL INDEX

Front wiperEL-109
FUEL - Wiring diagramEC-308, 315
Fuel cut control (at no load & high engine speed)EC-97, 505, 756
Fuel filter.....EC-102
Fuel filter replacement (YD engine).....MA-20
Fuel filter replacement (ZD engine).....MA-28
Fuel gauge.....FE-4
Fuel injection system.....EC-306, 313, 503, 754
Fuel injector.....EC-43, 438
Fuel line inspection (YD engine)MA-21
Fuel line inspection (ZD engine).....MA-29
Fuel pressure check.....EC-102
Fuel pressure regulatorEC-103
Fuel pressure releaseEC-102
Fuel pumpEC-46, 74, 447
Fuel pump relayEC-46, 447
Fuel systemFE-4
Fuel tank.....FE-4
Fuel tank vacuum relief valveEC-99
Fuse blockFoldout

G

Gauges.....EL-61
Generic scan tool (GST)EC-149
GLOW - Wiring diagram.....EC-472
Glow plugEC-713, 964
Glow relayEC-713, 964
GreaseMA-10
Ground clearance (Dimensions).....GI-12

H

H/AIM - Wiring diagramEL-40
Harness layout.....EL-180
Hazard warning lamp.....EL-52
Headlamp.....EL-26
Headlamp aiming control.....EL-40
Headlamp removal and installationBT-2
Headlamp washerEL-116
Heat up switchEC-730, 981
Heated oxygen sensor (HO2S).....EC-36
Heated oxygen sensor (HO2S) (front).....EC-265, 271, 282, 379, 386
Heated oxygen sensor (HO2S) heater (front)EC-202
Heated oxygen sensor (HO2S) heater (rear)EC-207
Heated oxygen sensor (rear)EC-289, 296, 393, 403
Heated seat.....EL-131
HEATER - Wiring diagramHA-4
HEATUP - Wiring diagramEC-731, 982
Height (Dimensions).....GI-12
H/LAMP - Wiring diagram.....EL-26
HLC - Wiring diagramEL-116
HO2S - Wiring diagram.....EC-36, 37

Hood.....BT-2
Horn.....EL-117
HORN - Wiring diagram.....EL-117
How to erase DTC for OBD system.....EC-129, 520, 768
HSEAT - Wiring diagram.....EL-131

I

IACV - air regulatorEC-76
IACV-AAC valve.....EC-38, 69, 364
IACV-FICD solenoid valveEC-48, 458
IATS - Wiring diagramEC-231, 597, 850
Idle air control (IAC) systemEC-364
Idle air control valve (IACV)EC-364
Idle mixture ratio.....EC-104
Idle speedEC-104, 536, 784
IGN/SG - Wiring diagram.....EC-29, 59, 66
Ignition control systemEC-430
Ignition timingEC-104
IGNSYS - Wiring diagramEC-432
ILL - Wiring diagramEL-55
IlluminationEL-55
INJECT - Wiring diagram.....EC-43, 72, 439
Injection nozzleEC-507, 758
Injector.....EC-43, 72
Injector removal and installationEC-103
INT/L - Wiring diagram.....EL-60
INT/V - Wiring diagramEC-996
Intake air control valve control solenoid valveEC-994
Intake air temperature sensorEC-229, 262, 595, 848
Intake manifold (KA24DE engine)EM-12
Intake manifold (ZD engine)EM-93
Interior lamp.....EL-59
ISC - FI pot.....EC-57

K

Keyless entry system - See Multi-remote control system.....EL-150
Knock sensor (KS).....EC-329, 330
KS - Wiring diagram.....EC-330

L

Length (Dimensions)GI-12
License lamp.....EL-42
Liquid gasket applicationEM-3
LOAD - Wiring diagram.....EC-52
Location of electrical unitsEL-177
Lubricants.....MA-10
Lubrication circuit (YD engine)LC-4
Lubrication circuit (ZD engine)LC-18

ALPHABETICAL INDEX

M

MAFS - Wiring diagramEC-24, 64, 215, 223
 MAIN - Wiring diagramEC-13, 14, 61, 193,
 562, 810
 Main gear (Transfer)TF-4
 Mainshaft (Transfer).....TF-4
 Maintenance (KA24DE engine)MA-12
 Maintenance (YD engine).....MA-13
 Maintenance (ZD engine)MA-22
 Malfunction indicator (MI).....EC-130
 Malfunction indicator lamp (MIL).....EC-521, 769
 Manifold tightening torque (intake &
 exhaust) (YD engine)MA-13
 Manifold tightening torque (intake &
 exhaust) (ZD engine)MA-22
 Mass air flow sensor (MAFS)EC-23, 212, 220
 MeterEL-61
 METER - Wiring diagram.....EL-67
 MI & Data link connectors circuitEC-465
 MI/DL - Wiring diagramEC-465
 MIL & Data link connectors circuitEC-53
 MIL/DL - Wiring diagram..EC-53, 54, 77, 738, 1011
 MIRROR - Wiring diagram.....EL-128
 MisfireEC-320
 Model variationGI-4
 M/T removal and installationMT-2
 Mud guard - See ExteriorBT-6
 MULTI - Wiring diagram.....EL-151
 Multi-remote control system.....EL-150
 Multiport fuel injection (MFI) systemEC-93

N

NATS (Nissan anti-theft system)EL-157
 NATS - Wiring diagramEL-160
 Neutral position switch.....EC-39, 424
 NVH troubleshooting (EM) (ZD engine)EM-90

O

O2H1B1 - Wiring diagramEC-204
 O2H2B1 - Wiring diagramEC-209
 O2S1B1 - Wiring diagram.....EC-267, 274, 285
 O2S2B1 - Wiring diagram ...EC-291, 299, 396, 406
 Oil change (capacity)MA-10
 Oil change (interval).....MA-2
 Oil cooler (YD engine)LC-7
 Oil cooler (ZD engine)LC-23
 Oil filter (YD engine)LC-7
 Oil filter (ZD engine)LC-22
 Oil jet (ZD engine)LC-22
 Oil pan (YD engine)EM-19
 Oil pan (ZD engine)EM-104
 Oil pressure (YD engine)LC-5
 Oil pressure (ZD engine)LC-19
 Oil pump (YD engine).....LC-5

Oil pump (ZD engine)LC-20
 Oil pump regulator valve (YD engine).....LC-6
 Oil pump regulator valve (ZD engine)LC-21
 Oil seal replacement (ZD engine).....EM-131
 On board diagnostic systemEC-118, 520, 768
 Overheat.....EC-413

P

P/ANT - Wiring diagram.....EL-127
 Park/Neutral position switchEC-424, 725, 976
 Parking lampEL-42
 PCV (positive crankcase
 ventilation)EC-101, 506, 757
 PCV filter replacement (KA24DE
 engine)MA-12
 Periodic maintenance (except for
 Europe).....MA-2
 PGC/V - Wiring diagramEC-355
 Piston assembly (YD engine)EM-85
 Piston pin inspection (YD engine)EM-75
 Piston pin inspection (ZD engine)EM-151
 Piston ring inspection (YD engine)EM-75
 Piston ring inspection (ZD engine)EM-152
 Piston to bore clearance (YD engine)EM-77
 Piston to bore clearance (ZD engine)EM-155
 PLA - Wiring diagramEC-488
 PNP/SW - Wiring diagram.....EC-39, 40, 70, 427
 POWER - Wiring diagram.....EL-6
 Power door mirrorEL-128
 Power steering oil pressure switchEC-454
 Power supply routingEL-5
 Power transistor & ignition coil.....EC-430
 Power windowEL-133
 Priming pumpEC-536, 784
 PST/SW - Wiring diagramEC-47, 75, 455

Q

Quick-glow system.....EC-469, 713, 964

R

Radiator (YD engine)LC-15
 Radiator (ZD engine)LC-29
 Radiator fan - See Cooling fan (YD
 engine)LC-16
 Radiator fan - See Cooling fan (ZD
 engine)LC-30
 Rear case (Transfer).....TF-3
 Rear fog lampEL-50
 Rear window defoggerEL-120
 Refrigerant connection precautionHA-2
 Refrigerant linesHA-36
 R/FOG - Wiring diagram.....EL-50
 Road wheel sizeGI-11
 Rocker cover (ZD engine)EM-102

ALPHABETICAL INDEX

Room lamp.....EL-59
ROOM/L - Wiring diagramEL-59

S

Seat belt pre-tensioner.....RS-3
Seat belt pre-tensioner disposal.....RS-11
Self-diagnostic resultsEC-521, 769
SHIFT - Wiring diagramAT-34
Shift control (Transfer)TF-5
Shift lock systemAT-34
Side air bag.....RS-3
SMJ (super multiple junction).....Foldout
Specification valueEC-188
Spiral cable.....RS-6
Spot lamp.....EL-60
SRS - See Supplemental Restraint
System.....RS-3
SRS - Wiring diagramRS-18
S/SIG - Wiring diagram.....EC-44, 73, 444
START - Wiring diagram.....EL-14
Start signalEC-44, 443
StarterEL-19
Starting systemEL-14
Stop lamp.....EL-46
STOP/L - Wiring diagram.....EL-46
Supplemental Restraint System.....RS-3
Supplemental restraint system - Wiring
diagram.....RS-18
Swirl control valve control solenoid
valveEC-986
SWL/V - Wiring diagramEC-988
Symptom matrix chart.....EC-171, 542, 790
System readiness test (SRT) code.....EC-120

T

Tail lamp.....EL-42
TAIL/L - Wiring diagramEL-42
TCM circuit diagram.....AT-2
THEFT - Wiring diagram.....EL-156
Theft warning system.....EL-156
Thermostat (YD engine)LC-14
Thermostat (ZD engine)LC-27
Three way catalystEC-347
Throttle bodies (KA24DE engine).....EM-12
Throttle chambers (KA24DE engine).....EM-12
Throttle position sensor (TPS).....EC-33, 239, 251
Throttle position sensor adjustment.....EC-155
Throttle position switch.....EC-370

Timing chain (YD engine)EM-25
Timing chain (ZD engine)EM-107
Timing gear (ZD engine)EM-119
Tire sizeGI-11
TP/SW - Wiring diagramEC-372
TPS - Wiring diagramEC-33, 67, 243, 254
Tread-FR&RR (Dimensions).....GI-12
Turbocharger (ZD engine)EM-95
TURN - Wiring diagramEL-52
Turn signal lampEL-52
Two trip detection logic.....EC-118

V

Vacuum hose drawing (Engine control)EC-91
Vacuum pump (ZD engine).....EM-106
Valve clearance (YD engine)EM-63
Valve clearance (ZD engine).....EM-116
Valve guide (YD engine).....EM-55
Valve guide (ZD engine)EM-140
Valve lifter (ZD engine)EM-113
Valve seat (YD engine).....EM-57
Valve seat (ZD engine)EM-141
Valve spring (YD engine).....EM-58
Valve spring (ZD engine)EM-141
Vehicle identification number.....GI-8
Vehicle speed sensor (VSS).....EC-34, 359, 576, 824
VSS - Wiring diagram.....EC-34, 35, 68, 361

W

WARN - Wiring diagramEL-88
Warning chimeEL-106
Warning lampsEL-86
Washer, front.....EL-109
Water pump (YD engine).....LC-13
Water pump (ZD engine).....LC-26
Wheel sizeGI-11
Wheelbase (Dimensions)GI-12
Wide open & closed throttle position
switch.....EC-239, 251
Width (Dimensions)GI-12
WINDOW - Wiring diagramEL-135
WIPER - Wiring diagram.....EL-110
Wiper, front.....EL-109
Wiring Diagram (Cell code) list.....EL-221
Wrist pin - See Piston pin inspection
(YD engine).....EM-75