Go to SUP13

NISSAN
MODEL D22 SERIES

QUICK REFERENCE INDEX

General Information	GI
Maintenance	MA
Engine Mechanical	EM
Engine Lubrication & Cooling System	LC
Engine Control System	EC
Accelerator Control, Fuel & Exhaust System	FE
Clutch	CL
Manual Transmission	MT
Automatic Transmission	AT
Transfer	TF
Propeller Shaft & Differential Carrier	PD
Front Axle & Front Suspension	FA
Rear Axle & Rear Suspension	RA
Brake System	BR
Steering System	ST
Restraint System	RS
Body & Trim	BT
Heater & Air Conditioner	HA
Electrical System	EL

©2013 NISSAN MOTOR CO.,LTD.

All Rights Reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, recording or otherwise, without the prior written permission of NISSAN MOTOR CO., LTD.

FOREWORD

This supplement contains information concerning necessary service procedures and relevant data for the 2011 NISSAN model D22 series.
All information, illustrations and specifications contained in this supplement are based on the latest product information available at the time of publication. If your NISSAN model differs from the specifications contained in this supplement, consult your NISSAN distributor for information.
The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.
The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.
Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.

NISSAN MOTOR CO., LTD.